

FIG. 1

FIG. 2


26
MULTICAST CONTENT
28
DETERMINE STATUS
30
MISSING DATA?
NO
YES
34
RANDOM DELAY
42
RECEIVERS RECEIVE NAK MULTICAST
NAK UNICAST
36
44
MISSING SAME ELEMENT?
NO
SERVER RECEIVES NAK UNICAST
38
YES
45
SUPPRESS NAK
SEND MULTICAST
40
46
WAIT FOR REPAIR MULTICAST
SEND REPAIR MULTICAST
48
CORRECT DATA
50
END
32